

## How to use

- Press the bar into the body hole,rotate key-barrel anticlockwise;
- ✓ The lock will give " D" sound to show that the alarm system starts to work;
- ✓ To cancel the auto alarm function, double turning the key-barrel in 5 seconds, when listen the warning tone "D-D" , the system is set into no alarm mode, shown as Figure 1.



Figure 1

## **Battery installation**

Shown as the drawing beside.

